

TIMEX

www.timex.com

W-205 191 095002 EU

Your TIMEX Pedometer will track steps during your workout – whether you're walking, jogging or running!

Please read instructions carefully to understand how to operate your Timex Pedometer.

Visit www.timex.com for more state-of-the-art TIMEX technology to help you reach your fitness goals and maintain your healthy lifestyle.

HOW TO WEAR YOUR PEDOMETER

- Slide the clip (Figure A) on the back of the pedometer completely onto your belt or waistband (Figure B) as close to your hip bone as possible so that the buttons face away from your body (Figure C). Be sure the pedometer remains firmly attached during your exercise.



Figure A



Figure B



Figure C

HOW TO COUNT YOUR STEPS


- Press RESET to clear the display of old data.
- Wear your pedometer according to the directions above.
- Begin your activity, your steps will be counted up to 99,999.

HOW TO CHANGE THE BATTERY

The display will begin to dim as the battery runs down. Change the battery as soon as you notice the display quality declining. Your pedometer uses a LR44 (or equivalent) battery available at many electronics stores.

- Use a coin or a screwdriver to remove the battery cover. See diagram below.
- Remove the dead battery and replace with the new one. Be sure "+" is facing up and the battery is seated firmly in the well.
- Replace the battery cover and make sure it is fully closed.
- Dispose of the old battery.

NOTE: Replacing the battery clears all your pedometer's data.



**DO NOT DISPOSE OF BATTERY IN FIRE. DO NOT RECHARGE.
KEEP LOOSE BATTERIES AWAY FROM CHILDREN.**

TIMEX INTERNATIONAL WARRANTY
(U.S. – LIMITED WARRANTY)

Your TIMEX Pedometer is warranted against manufacturing defects by Timex Corporation for a period of ONE YEAR from the original date of purchase. Timex and its worldwide affiliates will honor this international warranty.

Please note that Timex may, at its option, repair your Pedometer by installing new or thoroughly reconditioned and inspected components or replace it with an identical or similar model. **IMPORTANT – PLEASE NOTE THAT THIS WARRANTY DOES NOT COVER DEFECTS OR DAMAGES TO YOUR PEDOMETER:**

1. after the warranty period expires;
2. if the pedometer was not originally purchased from an authorized Timex retailer;
3. from repair services not performed by Timex;
4. from accidents, tampering or abuse; and
5. lens, belt clip, case, attachments or battery. Timex may charge you for replacing any of these parts.

THIS WARRANTY AND THE REMEDIES CONTAINED HEREIN ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE. TIMEX IS NOT LIABLE FOR ANY SPECIAL INCIDENTAL OR CONSEQUENTIAL DAMAGES. Some countries and states do not allow limitations on implied warranties and do not allow exclusions or limitations on damages, so these limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from country to country and state to state.

To obtain warranty service, please return your pedometer to Timex, one of its affiliates or the Timex retailer where the pedometer was purchased, together with a completed original Repair Coupon or, in the U.S. and Canada only, the completed original Repair Coupon or a written statement identifying your name, address, telephone number and date and place of purchase. Please include the following with your pedometer to cover postage and handling (this is not a repair charge); a US \$7.00 check or money order in the U.S.; a CAN \$6.00 cheque or money order in Canada; and a UK £2.50 cheque or money order in the U.K. In other countries Timex will charge you for postage and handling. NEVER INCLUDE ANY OTHER ARTICLE OF PERSONAL VALUE IN YOUR SHIPMENT.

For the U.S., please call 1-800-328-2677 for additional warranty information. For Canada, call 1-800-263-0981. For Brazil, call 0800-168787. For Mexico, call 01-800-01-060-00. For Central America, the Caribbean, Bermuda and the Bahamas, call (501) 370-5775 (U.S.). For Asia, call 852-2815-0091. For the U.K., call 44 020 8687 9620. For Portugal, call 351 212 946 017. For France, call 33 3 81 63 42 00. For Germany, call +43 662 88 92130. For the Middle East and Africa, call 971-4-310850. For other area, please contact your local Timex retailer or Timex distributor for warranty information. ©2004 Timex Corporation. TIMEX is a registered trademark of Timex Corporation in the US and other countries.

**TIMEX INTERNATIONAL WARRANTY —
REPAIR COUPON**

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

**THIS IS YOUR REPAIR COUPON.
PLEASE KEEP IT IN A SECURE PLACE.**